


**INSTRUCTION SHEET**  
**SUBJECT: CORE SLIDERS**  
**REPLACEMENT FOR MODELS 180, 210 & 230**  
**(PART NO. SV68026)**

**⚠ WARNING**

**It is recommended to wear safety glasses and gloves while performing these instructions.**

- ① Turn the unit OFF using wall control. Unplug the unit.
- ② Remove the core and filters.




- ③ Unscrew plastic screw using long nose pliers then pull out the core slide. Repeat this step on the other side of the unit.
- ④ Finalize the installation by reversing steps ③ to ①.

**FEUILLE D'INSTRUCTION**  
**OBJET : REMPLACEMENT DES GLISSIÈRES**  
**DE NOYAU POUR LES MODÈLES 180, 210 & 230**  
**(PIÈCE N° SV68026)**

**⚠ AVERTISSEMENT**

**Il est recommandé de porter des lunettes et des gants de sécurité lors de l'exécution de ces directives.**

- ① Arrêter le fonctionnement de l'appareil à l'aide de la commande murale. Débrancher l'appareil.
- ② Enlever le noyau et les filtres.



- ③ Dévisser la vis en plastique à l'aide d'une pince à long bec, puis tirer la glissière du noyau. Répéter cette étape de l'autre côté de l'appareil.
- ④ Finaliser l'installation en inversant les étapes ③ à ①.